

# ***High-Speed Riverboat Assembly Instructions***

---



## **Outriggers and Crossbar**

The High-Speed Riverboat platform assembles in two easy steps.

Attach the Outriggers to the Crossbar using the  $\frac{1}{4}$ -20 x 1  $\frac{3}{4}$  inch screws with lock and flat washers (Figure 1).



**Fig.1: Outriggers attached to crossbar.**

## **Main Hull and Crossbar**

Next, attach the Main Hull to the Crossbar using the  $\frac{1}{4}$ -20 x 1" screws with lock and flat washers provided (Figure 2).



**Fig. 2: Main hull and outriggers attached to crossbar.**