

Lead Pocket Ballast Installation

Figure 1



Figure 2



Figure 3



Figure 4



1. You will need: 3/8" x 3" Hex Bolts, 3/8" Flat Washer, and 3/8" Spring Lock Washer from the Lead Weight Attachment Hardware Bag. (Figure 1)
2. Apply anti-seize compound to the threads of the hex bolts. (Figure 2)
3. Place the Lock Washer and then the Flat washer onto the hex bolt. (Figure 3)
4. Place the ballast weight into the pocket. Thread the hex bolt into the center hole by hand until the threads are started. Using a 9/16" socket tighten the bolt until the spring washer flattens. **Do not over-tighten**